



VeGA 4618 SXH 5in1

2017

No.	ID Zboží	Název
1	21041000063201B	blade tighten bolt
2	2105200010C	blade
3	21051000220001N	motor centrifugal cutter
4	2105400015C	centrifugal cutter bush
5	A26800300502	screw
6	2102300148A	driving belt wheel
7	2102600048C	triangle belt
8	A26809003701	flat key
9	A26800901901	block ring for axis
10	A26800500801	hex locking nut
11	A26800103701	self-driving screw
12	A26800700701	flat ring
13	21041001910001C	belt wheel protecting cover
14	A26800100501	self-driving screw
15	21041002970001A	front panel handle
16	21041002950006A	head cover
17	21041002960001A	cover board
18	21011003670006B	wheel cover-1
19	A26800502801	hex flange locking nut
20	2101300065A	bearing
21	21011002660001A	wheel ass'y
22	A26800706202	wave washer
23	A26800611901	hex flange bolt
24	21011001023201B	lower support of wheel axle
25	2101500077C	front wheel axle ass'y
26	21011002893201B	upper support of wheel axle
27	A26800500501	hexagonal locking nut
28	2109800134A	spring of front wheel axle
29	A26800201901	tooth screw
30	2106200128A	wheel axle fixed ring
31	A26800502401	locking screw
32	A26800900201	open block ring
33	2104400013E	left output gear ass'y
34	A26800705102	flat washer
35	A26800402302	bearing
36	2102400156D	bearing sheath
37	A26809000102	column pin
38	2102300058B	gear box
39	2104400014E	right output gear ass'y
40	A26800611201	hexagon flange bolt
41	2102300154A	position fixing plate
42	2106200554C	position fixing board
43	2106200053N	side-discharge position fixing
44	A26800800402	spring washer

No.	ID Zboží	Název
45	A26800201501	tooth screw
46	2109800066D	side cover board spring
47	21061005340001A	side-discharge cover board
48	21041001313209C	side-discharge protecting cover
49	21011000620006C	wheel cover-1
50	21011001700001N	wheel ass'y
51	2101100081B	wheel gear ring
52	21011003730001F	11" dust-proof wheel cover
53	2101500206A	rear wheel axle ass'y
54	A26800900301	open block ring
55	2109200020A	adjusting washer
56	21061003944017A	height adjustment board
57	21062010010002A	deck
58	21091000363200A	cable pressing bracket
59	2208100010A	cable pressing board
60	A26800100302	self-driving screw
61	2106200818A	connecting rod
62	2106600013A	cable protecting sheath
63	2106200815A	handle ass'y
64	A26800303301	screw
65	21061002883047A	height adjustment ass'y
66	A26800606401	hexagon flange bolt
67	21062001660002B	right handle bracket
68	2109800072A	right knob spring
69	2106300028B	long rod
70	2109800071A	left knob spring
71	21062001650002B	left handle bracket
72	A26800304401	special bolt
73	A26800612501	hex bolt
74	2109200029B	flat washer
75	21041002120001A	wind sleeve(lower)
76	2011200066A	capacitor
77	21041000103201A	motor locking bolt
78	A26800801002	tooth locking washer
79	2050100062A	induction motor
80	21081000173200N	motor fan
81	21041002110001A	wind sleeve(upper)
82	21041001760001B	right wind inlet board
83	21041002320006A	motor cover
84	21041001750001B	left wind inlet board
85	21041002960001A	cover board
86	21061000170001A	connecting wire protecting
87	A26800600401	flat head bolt
88	21061000113201A	curled washer

No.	ID Zboží	Název
89	21061000020182B	lower handle knob
90	A26800502301A	hex nut
91	2106100003A	tube plug
92	21061000013201A	cable clamp
93	21061001543201N	lower adjustment gear
94	A26800104902	self-driving screw
95	21062003190001B	lower handle
96	A26809004801A	column pin
97	21061000270002A	locking handle
98	2109200025A	pressing plate
99	2109300026A	locking handle bolt
100	21061001533201C	upper adjustment gear
101	A26800612002	flat head bolt
102	2106800322A	driving cord ass'y
103	21061000043201A	self-driving screw
104	A26800700801	flat ring
105	A26800501603A	cap nut
106	21061004400001N	block ring
107	21061001380001A	cable hook ring
108	2011100083N	power cord
109	21061000223208A	cable sheath
110	2106900002A	connecting wire
111	21061000160001A	connecting wire protecting
112	21041002073201B	switch box(right)
113	21061001560002B	switch button
114	2224200003A	spring of transfer board
115	2109100038A	cable pressing board
116	2011400013D	arc switch
117	21041002063201N	left switch box
118	21041002083201N	pressing board of switch box
119	21041004680001B	left handle support
120	21061001643201A	cord connecting buckle
121	2106800260B	driving cord ass'y
122	21041000980001B	right handle support
123	21061001580002A	right handle plug-in
124	2106800004A	right plug-in spring
125	A26800103602	self-driving screw
126	21061000183012A	lamp shade

No.	ID Zboží	Název
127	2106100023A	indication light
128	A26800303101	heteromorphosis screw
129	21062004090001B	upper handle
130	A26800102101	self-driving screw
131	21061001570002A	left handle plug-in
132	2106800003B	right plug-in spring
133	21062003030002N	start handle
134	2106100311A	handle sheath
135	A26800104601A	self-driving screw
136	21061001113201N	wave washer
137	21061001603201B	right bracket of driving pole
138	21061001623201A	washer of pulling pole bracket
139	21061001803201B	self-propelled cord hanging
140	21061001613201A	cover board of pulling pole
141	21061001593201B	left bracket of driving pole
142	21062004190001N	driving pole
143	21041001160001A	knob pressing board
144	2109800022C	spring
145	21041001150182A	mulching kit button
146	21061000930001A	mulching kit
147	21071000050001	handle of grass catcher
148	21071000520001A	grass catcher
149	2100X04474	rear board ass'y
150	2107200024C	grass catcher bracket
151	21071000080002	level indicator
152	A26800103202	self-driving screw
153	21077000462147A	grass catcher
154	2103200002A	spanner
155	A26800702101	washer